

size:210\*140mm

### □ Disassemble the lid

- 1.Remove the silicone ring
- 2.Place the lid on the horizontal table top and make sure the handle is taken out in the right direction.
- 3.Firmly hold the top half of the lid and remove the handle while the handle is standing up.
- 4.Top half of lid, bottom half of lid, handle, spring




### □ Assemble the lid

- 1.Handle mounting part of bottom lid facing forward (hole facing self)
- 2.The spring is placed on the mounting part of the handle (the top is large and the bottom is small, with the small diameter end placed on the bottom).
- 3.Cover the upper half of the lid, press the whole down hard, and buckle in the state of the handle upright.
- 4.Set the silicone ring properly.



### □ Silicone ring installation

The silicone ring needs to be removed and cleaned. Be sure to install it properly before using it.



As shown, the concave part of the lid and the convex part of the silicone ring are embedded and assembled together.